

PRO CT416

NO.		Description	QTY
1	04.04.119.001	Front Panel	1
2	02.05.003.003	Switch-1	2
3	02.03.004.006	Indicator Light	1
4	02.05.009.012	Fuse	1
5	02.05.003.010	Switch-2	1
6	08.10.003.013	Current Knob	1
7	03.01.004.019	Fast Connector	2
8	03.01.003.001	Connector-1	1
9	03.01.002.001	Connector-2	1
10	08.06.006.003	Rubber-1	4
11	04.04.119.005	Output Connector	3
12	01.09.001.001	Potentiometer Setting Knob	1
13	07.02.012.011	Board	1
14	04.04.119.002	Base	1
15	02.04.011.013	Solenoid Valve	1
16	02.04.009.003	Transformer	1
17	08.10.004.003	Cable Clip	1
18	02.04.012.021	Fan	1
19	03.05.012.002	Fan Net	1
20	07.02.003.048	Power P.C Board	1
21	07.02.002.041	Diode Bridge	1
22	02.03.017.021	Rectifier P.C Board	2
23	08.01.001.036	Vertical Beam	4
24	04.04.105.009	Baffle-1	2
25	03.02.016.031	Radiator	2
26	08.02.001.072	Inverter Insulation Board	1
27	04.04.119.006	Baffle-2	1
28	07.02.001.044	Inverter P.C Board	1
29	04.04.119.007	Horizontal Beam	2
30	08.07.007.009	Rubber-2	2
31	08.08.001.006	Handle	1
32	04.05.108.012	Main Case	1

